

# Coherent X-ray Diffraction for mapping strains in ZnO Nanocrystals

Ian Robinson

Ross Harder

Steven Leake

Marcus Newton

Loren Beitra

London Centre for Nanotechnology

Diamond Light Source

DPG March Meeting

Regensburg


March 2010

# Outline


- Coherent x-ray diffraction
- Oversampling solves the **phase** problem
- Nanocrystal structures
- Exploration of crystal strain
- Effects of partial coherence

# Size-dependent Melting of Au Particles

P. Buffat and J-P. Borel, Phys. Rev. A 2287-97 (1975)




# Chemical Synthesis of Nanocrystals





- Reactants introduced rapidly
- High temperature solvent
- Surfactant/organic capping agent
- Square superlattice (200nm scale)

C. B. Murray, *IBM J. Res. & Dev.*  
**45** 47 (2001)




# VLS growth of nanowires

S. Kodambaka et al., *Science* 316 729 (2007)




I. K. Robinson, Regensl  
NiSi/Si nanowire heterostructure devices. *Nature* **430**, 61 (2004).

# Lensless X-ray Microscope, 2003



# Generic “Error Reduction” method





J. R. Fienup *Appl. Opt.* 21 2758 (1982)


R. W. Gerchberg and W. O. Saxton *Optik* 35 237 (1972)






I. K. Robinson, Regensburg 2010

Chemically Synthesized  
Silver Nanocube  
Rock with  $0.01^\circ$  steps


Yugang Sun and Younan Xia,  
Science 298 2177 (2003)








# Coherent Diffraction from Crystals







# Sensitivity to strain

$$\Delta\varphi = \mathbf{k}_f \cdot \mathbf{u} - \mathbf{k}_i \cdot \mathbf{u} = \mathbf{Q} \cdot \mathbf{u}$$




# ZnO Sample Preparation



I. K. Robinson, Regens

# Density sections ZnO-39 (010)


Marcus Newton et al, Nature Materials (2010)




K. Robinson, Regensburg 201

# Phase maps from 2 Bragg peaks

Blue-Red is +2 radians. Slice at -1500nm from centre ZnO-5 -39




# Typical displacement field




# 2D vector field of displacements

Marcus Newton et al, Nature Materials (2010)




# Extension to 6 Bragg Peaks




# Extension to 6 Bragg Peaks

Marcus Newton et al, Nature Materials (2010)




# Full Strain Tensor

$$\epsilon_{ij} = \frac{1}{2} \left( \frac{\partial u_j}{\partial x_i} + \frac{\partial u_i}{\partial x_j} \right), \quad \tau_{ij} = \left( \frac{\partial u_j}{\partial x_i} - \frac{\partial u_i}{\partial x_j} \right)$$




# ZnO Rigid-body Rotations




# Partial Beam Coherence

Line scan to extract the contrast visibility



# Five Bragg peaks




002 no fringe visibility

010 & 100 good fringe visibility


101 & 011 diminished fringe visibility but fringes still evident

# Fringe Visibility $96 \pm 2\%$ @010



# Measured Longitudinal Coherence


Steven Leake, Optics Express 17 15853 (2009)





I. K. Robinson, Regensburg 2010

# Density Section of Reconstruction using 100 and 101 reflections



“hot spot” more developed for limited coherence  
Steven Leake, Optics Express 17 15853 (2009)



# Confocal Alignment Microscope






# Single Au nanocrystal synthesis




# Two views of strain in Au NC

Au409B-52 (11-1) and Au409B-60 (200)







1,1,-1



1,-1,1





-1,1,1




100 nm

2,0,0



I. K. Robinson, Regensburg 2010

0,2,0




0,0,2

30

# Vector displacement field

Merged reconstructions from (11-1) (020) and (-111)



# Conclusions

- Internal structure of Nanocrystals
- Phasing by computation instead of lens
- Strain fields imaged from asymmetric patterns
- Full Strain Tensor accessible
- Partial Coherence affects Image Quality